PORTABLE INNOVATION TECHNOLOGY LTD.

MemPlug™

COMPACT FLASH ADAPTOR
MEMORY STICK™ ADAPTOR
SD / MMC CARD ADAPTOR
SMARTMEDIA™ ADAPTOR

User Guide

Table of Contents

Table of Contents.....i-ii

Quick Start Guide.....1-4
- what do you need?..... 1
- installing memplug 2-3
- faq 3
- product registration 4

PiPrefs 5-6
- product features 5
- screen shots 5
- operating instructions 6
- faq 6

PiMover 7-16
- product features.....7
- screen shots.....7
- operating instructions.....8-14
- faq..... 15-16

PiBackup.....17-18
- product features.....17
- screen shots.....17
- operating instructions.....17
- faq.....18

PiViewer.....19-20
- product features.....19
- screen shots.....19
- operating instructions.....20
- faq.....20

CSpotRun..... 21-22
product features..... 21
screen shots..... 21
operating instructions.....22
faq.....22

PiVFSMgr.....23-28
product features.....23

quick start guide.....23
operating instructions.....23-27
remarks.....27
faq.....28

PiDirect..... 29-38
product features.....29
requirements.....29
quick start guide.....29
operating instructions.....30-37
how to purchase pidirect.....37
faq.....38

gMovie Maker & Player.....39-40
product features.....39
installations.....39
operating instructions.....40

Online Resources.....41-42

Warranty Terms and Conditions.....43-44

Quick Start Guide

What do you need?

MemPlug Compact Flash Adaptor
(Most Type I Compact Flash Card) *except Memorex card

MemPlug Memory Stick Adaptor
(Memory Stick or Magic Gate Memory)

MemPlug SmartMedia Adaptor
(3.3V SmartMedia Memory Card)

MemPlug SD/MMC Adaptor
(SD or MultiMedia Memory Card)

Handspring Visor Handheld Computers
(Visor Deluxe, Edge, Neo, Platinum, Pro, Prism or Solo)

Installing MemPlug

Step 1 Remove the Springboard cover from the back of your Visor handheld. Insert the MemPlug Springboard module as shown in the picture below. Press firmly to ensure that it is fully inserted into the Springboard connector.

Step 2 Insert the Memory Card into the open slot at the top of the MemPlug module.



Step 3 MemPlug Springboard module includes seven self-installing applications

1. PiPrefs 2. PiMover 3. PiBackup 4. PiViewer 5. PiDirect (evaluation)
6. gMovie 7. CSpotRun

When a Memory Card is fully inserted, these seven applications should automatically install onto your Visor and you are ready to go!

FAQ

Q1. How come non of the MemPlug applications shows up after the memory card is inserted?
A1. Make sure the memory card is inserted with the correct orientation as shown. Otherwise, reinstall the MemPlug fireware using the latest software updater downloadable at www.pitech.com.

Q2. How come Fatal Error occurs right firmware after the Memory Card is inserted?
A2. The MemPlug firmware could be corrupted. You need to erase and then reinstall the MemPlug software. Consult the Customer Support page at www.pitech.com for details.

Product Registration

Please register your Memplug at www.pitech.com for all Software updates. You need the product Serial Number that is found at the back of the Memplug module.